

# OPERATING MANUAL

## PLACING THE MACHINE INTO OPERATION:

- Plug in the machine (230V/50 Hz)
- Press the **general switch [(1) green]**. The control light is on.
- Press the **start button [(2) orange]** drücken. The control light is on. The machine starts heating up.
- Place a cutlery collecting basket below the cutlery outlet at the front.
- Make sure to operate with the right quantity of granulate (approx. 6 kg): In operation the product must cover the middle of the first perforated grid. Press the **start button [(2) orange]** while lifting the top cap, check the quantity and close the top lid again.
- The operating temperature (about 50 °C) is reached, when the display shows the message: „<OK><Cutlery please>“.
- Take the clean and wet cutlery out of the water vessel, let the water rinse of for a moment and put the cutlery into the top opening.

★ **TIP:** To protect the beige mat at the top opening and the bulk coating we suggest to load knives always with handle first.

👉 **IMPORTANT:** The loaded cutlery *must* be clean and wet. Put it immediately into a clean water vessel after been cleaned by the dishwasher.

★ **TIP:** To improve the polishing result put a dash of vinegar into the water vessel.



## END OF OPERATION:

After polishing the machine automatically begins with the final drying process. After this the machine turns in the standby-modus.

If the display shows the message „<Off>“ you could power down the machine by pressing the **general switch [(1) green]**.

Plug off the machine.



## EMERGENCY:

- Push the **emergency stop [(3) red]** and eliminate the problem.
- Clear the **emergency stop [(3) red]** with a little turn clockwise (following the arrow)!
- Start working again as indicated in “Putting the machine into operation”.



## CLEANING:

At least once a day (after end of operation) as indicated in the operating manual.