

OPERATION MANUAL

PLACING THE MACHINE INTO OPERATION:

- Plug in the machine (230V/50 Hz).
- Push the *general switch [(1) green]*.
- Push the *start button [(2) blue]*.
The machine begins to vibrate and after the system test ends okay, the machine starts with the heating.
- Place a cutlery collecting basket below the cutlery outlet at the front.
- The heating ends, when the machine reaches the temperature of 80 °C. On the display the following message is shown: "BETRIEBSBEREIT". It means that the machine is ready to work.
- Nehmen Take the clean and wet cutlery out of the water vessel, let the water rinse off for a moment and put the cutlery into the cap opening.

★ **TIP:** To protect the mat at the cap opening and the bulk coating we suggest to put in knives always with handle first.

☞ **IMPORTANT:** The cutlery *must* be cleaned and wet before you put it into the polisher.

END OF OPERATION:

After polishing, the machine begins automatically with the final drying process and switch off after 30 minutes.

Push the *general switch [(1) green]* to switch off the machine totally.

CLEANING:

At least once a day (after end of operation) as explained in the operating manual.

